

Truck Computer Troubleshooting

Last Modified on 01/08/2026 10:30 am EST

Mobile Devices

- [? No Power](#)
- [? Screen Dims while in Docking Station](#)
- [? Not Communicating with Meter](#)
- [? LC Meter will not Reset to 0.00](#)
- [? Truck Computer Letters/Numbers not Working/CFU1](#)
- [? Screen Blank or Gray](#)
- [? Power or Connections not Working](#)
- [? Cannot Use On-Screen Keyboard](#)
- [? Cannot Increase Right-Click Button](#)
- [? Cannot Zoom In and Out](#)
- [? Truck Computer will not Turn Off](#)
- [? Cannot Turn Lights On On Keyboard](#)

Printers

- [? Blank Pages Print after Invoice](#)
- [? Will not Print from Truck Computer](#)
- [? Will not Print from Meter Stub/Block](#)
- [? Reprinted Tickets Display too Small Font](#)
- [? Print is Jumbled](#)

Power Supply: Charge Guard

[?](#) Intermittent Green Light

[?](#) Flashing Green Light

[?](#) Four Red Flashing Lights

[?](#) Two Red Flashing Lights

Power Supply: FP601

[?](#) Power or Connections not Working

Docking Station

[?](#) No Power to Docking Station

[?](#) Intermittent Cradle Connectivity